

BORGESON

Steering You Forward

#802413 Ford FE 390/428 P/S Pump Bracket

Installation notes:

- 1) This bracket set includes 2 short spacers and 2 long spacers. Cars ***without*** A/C will need to use both the short and long spacers. Cars ***with*** A/C will only need the 2 long spacers.

Installation:

- 1) Attach the bracket to the driver's side cylinder head as shown with the included two bolts, washers and the proper amount of spacers for your application.
- 2) Attach the P/S pump to the bracket with either the 3/8 or M10 bolts and washers depending on the P/S pump you are using. The bracket mounts to the back of the P/S pump. You may need to remove existing mounting studs.



Borgeson Universal Co., Inc.
9 Krieger Dr. Travelers Rest, SC 29690
www.borgeson.com