



Installation instructions

#0060

Transmission Adapter

1963 - Up Chevy V8 Engine

To

1966 – Up Olds, Buick, Pontiac and Cadillac-Super Turbine 300,
TH350, TH400

This Kit Contains

<u>Qty</u>	<u>Description</u>
1	Steel Adapter Plate
6	3/8" Flat Washers
6	5/16" Flat Washers
4	3/8 – 24 x 1" Hex Head Bolts
3	3/8 – 16 x 1" Hex Head Bolts
2	3/8 – 16 x 1 1/2" Hex Head Bolts
2	3/8 – 24 x 1" Flat Head Socket Screws

1. Bolt adapter plate to the rear of the Chevrolet V8 Engine using the 3/8 – 16 x 1" bolts and the 3/8 – 16 x 1" Head Socket Screws included in this kit.
2. Use two 3/8 or 5/16 flat washers (depending on the bolt size used) on each converter bolt between the converter and the flex plate. *Torque to factory specs.*
3. Use the 3/8 – 24 x 1" Hex Head Bolts and the 3/8 – 16 x 1 1/2" Hex Head Bolts to mount the transmission to the plate and the engine. *Torque to factory specs.*
4. Use the stock flex when possible or use Chevrolet #471598.

Trans Dapt Performance Products
16410 Manning Way
Cerritos, Ca. 90703
Tel- (562)-921-0404 Fax (562)-921-7515
www.tdperformance.com