



# Set # 2-4105


POSITION # 1



POSITION # 2-3-4



POSITION # 5-6



← Front of vehicle

Must re-use original hardware.

© 2002 Energy Suspension. All rights reserved.  
May not be reproduced, in any form, or by any means,  
without the written consent of Energy Suspension.

## Removal


**Spray all nuts to be removed generously with your favorite rust buster.**

**Note:** When disassembling, note the quantity and positions of any shims that may have been inserted for body alignment. These shims will have to be reused to insure proper body alignment.

**Remember:** Only raise body high enough to remove & replace mounts. Always watch the fan shroud for sufficient clearance when raising the body. When jacking the body use a long enough 2X4 or 4X4 for maximum support. Never put jack directly on body panels.

Install mounts one side at a time with bolts on other side loosened only.

**Retorque to factory specs.**



**ENERGY**  
**SUSPENSION**  <sup>®</sup>

1131 VIA CALLEJON, SAN CLEMENTE, CA 92673