

Design Engineering, Inc.

604 Moore Road
Cleveland, OH 44012



THERMAL TUNING PRODUCTS

Installation Instructions

DEI Boom Mat™

PART NO. 050200 through 050212

KIT CHECKLIST	
PN #	Boom Mat Material

NOTE
It is not required to clean the surface of the area that the Boom Mat is being applied to but it does increase its bond strength.

DIRECTIONS

- 1 - Although Boom Mat will stick to anything, it is a good idea to make sure the installation area is clean and free of dirt, grease, oil, wax, moisture, and rust will improve the bond between Boom Mat and installation area.
- 2 - Trim Boom Mat to desired size by using a shape razorblade or scissors. Making a template will aid proper and professional installations. Remove the backing to expose the adhesive and carefully apply to clean and dry desired area.
- 3 - After Boom Mat is set in proper location, use a flat rolling pin and apply pressure to ensure a strong bond between the Boom Mat and installation surface.

