

Design Engineering, Inc.

604 Moore Road
Cleveland, OH 44012



THERMAL TUNING PRODUCTS

Installation Instructions

DEI Protect-A-Boot™

PART NO. 010501 through 010532 and PART NO. 010701 through 010732 in kits

KIT CHECKLIST	
2 or 8	Protect-A-Boots

NOTE
Protect-A-Boots are designed for use on most spark plug boots whether straight or 90-degree.

DIRECTIONS

- 1 - Remove spark plug wire from spark plug.
- 2 - Feed the large end of the Protect-A-Boot over the sparkplug boot and continue until the small end of the Protect-A-Boot meets the open end of the spark plug boot.
- 3 - Reinstall the spark plug wire on the spark plug.
- 4 - Again, watch that the Protect-A-Boot is not in direct contact with the header or exhaust manifold. The product's longevity could be greatly compromised.
- 5 - Repeat steps for remaining ignition wires.

