



20121 and 20121-09 Chevy Small Block Alternator Bracket Long Water Pump

- Kit no.
 22011 #5060410 alt. belt
 22021 #5060410 alt. belt - #5050335 P/S belt
 22031 #5060410 alt. belt - #5050335 P/S belt
 22041 #5060425 alt. belt
 22051 #5060425 alt. belt - #5060350 P/S belt
 22061 #5060425 alt. belt - #5060350 P/S belt

Alternator

Attach to back side of alternator, with One 5/16 Shoulder bolt.

1 5/8" Adjustment Rod with rod ends

One 3/8 16 x 1" SHCS, Attach to front side of water pump

Hole in upper left passenger side head

3.250" Spacer

Head

Alternator Lower Mount

Use One 3/8 16 x 6" SHCS

Two 3/8 16 x 1" SHCS

Use Loctite on all bolts

20121-A Alternator Bracket

