



Figure 1: Grille Guard Assembly.

1. Mount the rock crawler tube to the front bumper.
2. Use the hardware provided to mount the rock crawler grille guard.
3. Once all of the bolts are installed, torque all of the bolts to their proper torque.

⚠ WARNING

- **FAILURE TO SECURELY TIGHTEN ALL BOLTS ON THE FRAME BRACKETS AND BUMPER CAN RESULT IN PRODUCT FAILURE WHICH MAY RESULT IN VEHICLE DAMAGE AND OPERATOR INJURY OR DEATH. DOUBLE CHECK THAT ALL BOLTS ARE SECURELY TIGHTENED PRIOR TO USE.**

MAINTENANCE / CARE

- Inspect all nuts and bolts periodically. Tighten all nuts that appear to be loose. Stripped, fractured, or bent bolts or nuts need to be replaced.

CARELESS INSTALLATION AND OPERATION CAN RESULT IN SERIOUS INJURY OR EQUIPMENT DAMAGE. READ AND UNDERSTAND ALL SAFETY PRECAUTIONS AND OPERATING INSTRUCTIONS BEFORE INSTALLING AND OPERATING THIS PRODUCT.

