
UNIVERSAL APPLICATION TRACTION BARS WAR 670/671/672

1. Position your traction bar under the leaf spring with the front bracket in front of the axle, and the rear bracket behind the axle.
2. Use the supplied U shaped bolts and nuts to secure the bars to the leaf springs.
3. Install the polyurethane snubber bushing into one of the 3 holes in the front of the bar and use the hardware supplied to secure it. Adjust as necessary to reduce or increase wrap.
4. Repeat these steps for the other side.



This completes your Traction Bar installation.

If you need further assistance installing your product, please contact us by email at techsupport@warriorproducts.com or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS