

ANCHOR TIGHT® LOCKING FLEXIBLE ENGINE DIPSTICK INSTALLATION INSTRUCTIONS

STOP! Please read instructions completely before beginning installation. Call Lokar for any questions or uncertainties during the installation.

WARNING FOR 1979 AND EARLIER SMALL BLOCK CHEVY APPLICATIONS

Check to make sure that the factory GM lower dipstick tube (GM Part No. 3951600) is installed in the block before using an aftermarket Lokar dipstick. Failure to install this tube can result in damage to the dipstick or to the engine.

How to Use Locking Mechanism:

The Lokar dipstick has a locking quick disconnect fitting on the handle end. To remove the handle, slide the polished spring-loaded release ring away from the handle and pull up on the handle. To install the handle, slide the polished spring-loaded release ring away from the handle and push down on the handle and release the ring. **Photo 1**

- **Step 1:** Do not remove any nuts securing the stainless braided housing.
- **Step 2:** Clean the dipstick opening of the engine or oil pan, being sure it is free from all debris or burrs.
- **STEP 3:** Lokar locking dipsticks are engine specific. Be sure to install the correct dipstick for the application. To install the Lokar dipstick, remove the handle and inner measuring cable. It is advisable to put a small amount of silicone sealer on the shoulder of the bottom fitting. Install the dipstick into the opening.
- **STEP 4:** Route the flexible housing up though the headers as straight as possible and secure the upper mounting bracket to an existing header bolt. **Photo 2**
- **STEP 5:** Fill the engine to the full mark on the inner rod. Return the Engine Dipstick Handle and Inner Rod into the Stainless Braided Housing, being sure that the handle is snapped down in its locked position when checking the fluid level. This will assure that the engine oil is at the appropriate level. **Photo 3**

LOKAR, INC.

10924 Murdock Drive, Knoxville, TN 37932 Toll Free 1-877-469-7440

Ph: 865-966-2269 Fax: 865-671-1999 E-mail: tech@lokar.com or catalog@lokar.com www.lokar.com

©2007 Lokar, Inc. Rev. 11/27/07



PHOTO 1



PHOTO 2A



PHOTO 2B



РНОТО 3

LOKAR, INC. 10924 Murdock Drive, Knoxville, TN 37932 Toll Free 1-877-469-7440

Ph: 865-966-2269 Fax: 865-671-1999 E-mail: tech@lokar.com or catalog@lokar.com www.lokar.com

©2007 Lokar, Inc. Rev. 11/27/07